



réf. notice : 1503.107


αλφεινση

# 1




---



# 2



# 3 ✂



## PRECAUTIONS FOR USE :

EN



- Handle the device with care - do not drop it or subject it to strong impacts.
- This product is not waterproof, do not subject it to sprays of water or immerse it.
- For increased safety, avoid using the buttons during action. Loss of concentration can be dangerous

- Do not take the product apart, as this may lead to damage as well as cancellation of the warranty.
- If you plan not to use the product over a long period of time (over 1 month), make sure you remove the battery.
- Using the product in a very cold environment (temperature below  $-10^{\circ}\text{C}$ ) may lead to a reduction in battery capacity, and therefore the product's battery life.

## LIMITED LIABILITY :

EN

- GEONAUTE is not responsible for accidents or injuries caused by handling or using the product during high risk sports.
- In particular, GEONAUTE insists on informing the user of possible loss of concentration linked to using the product in dangerous conditions.
- The user is warned that they assume all legal liability for the taking, sharing, and publication of images recorded with the product.

## WARRANTY :

EN

- GEONAUTE guarantees the initial buyer of this product that it is exempt of faults relating to the materials or fabrication and does so for a period of 2 years (inclusive) from the date of purchase.
- Please keep your receipt as proof of purchase.
- The warranty does not cover damage caused due to

improper use, non-compliance with safety precautions, accidents, or the incorrect maintenance or commercial use of the device.

- This warranty does not cover damage resulting from repairs carried out by persons not authorised by GEONAUTE.

- The guarantees contained herein explicitly replace all other guarantees including the implicit guarantee of merchantability and/or suitability for use. GEONAUTE can, under no circumstances, be held responsible for any damage, direct or indirect, of a general or specific nature, caused by or related to use of these instructions or the product they describe.

- During the warranty period, the item will either be repaired free of charge by an authorised repair service or replaced free of charge (depending on the distributor).

- The warranty does not cover the battery, or casing that is cracked, broken or presents visible dents.



**EN ►** This product and the batteries it contains may not be thrown away with household waste. They are subject to a specific type of sorting. Take the batteries and unusable electronic product to an authorised collection area for recycling. This treatment of your electronic waste will protect the environment and your health

**This device complies with section 15 of the FCC Regulation. Operation is subject to the following two conditions :**

- 1 This device has no risk of producing harmful interference.
- 2 This device must accept all interference which occurs, including those which risk producing an undesirable functioning.

**This equipment has been tested and certified as complying with the limits of Class B numerical apparatus, under the provisions of Section 15 of the FCC. Those limitations are imposed to ensure reasonable protection against intrusive interference within a residential installation. This equipment generates, uses and emits radio energy frequencies and, if it has not been installed in accordance with the instructions, could provoke harmful interference to radio communications. However, there is no guarantee that it will produce no interference in any particular installation.**

**If this equipment provokes intrusive interference with radio or television reception, interference which can be ascertained by the device off and then switching it on again, it is recommended that the user take one of the following measures to remedy such interferences :**

- Reorientate or move the reception antenna.
- Increase the distance between the apparatus and the receiver.
- Link the equipment to a power supply on a circuit other than the one to which the receiver is linked.
- Seek advice from the vendor or from a radio/television technician.

**Warning:**

**Any change or modification which has not been expressly authorised by Décathlon is liable to delete the authorisation granted to the user for the use of the equipment.**

# GEONaute.com

oxylane

OXYLANE

4 Boulevard de Mons – BP 299

59665 Villeneuve d'Ascq cedex – France

