


i

réf. notice : 1503.112

## G-EYE REMOTE CONTROL

the remote control

1. Product description
 This remote control is to be used with the G-EYE 720p and G-EYE 1080p camera models. It enables you to control these cameras remotely. Please note: Maximum range = 5 metres Certain objects can adversely affect the range of



- Laser ON/OFF: hold down button 2 for 3 seconds
- If the battery indicator does not light up: either the signal has not been sent or the battery is empty.

Pairing the remote control with the camera
 The remote control must be paired with your
 camera.
 To do this follow the steps below:

To do this follow the steps below:

1.Keep the video recording button of the G-EYE camera pressed down

2.While pressing down the button, switch the G-EYE camera to ON

G-EYE camera to ON

3.Release the video recording button of the
G-EYE camera

4.Press buttons 1 and 3 on the remote control at the same time

the same time 5. You should hear a confirmation beep. 6. Check the pairing by trying to take a photo with the remote control.

the remote contro

3.Warranty GEONAUTE guarantees the initial buyer of this product that it is exempt of faults relating to the materials or fabrication and does so for a period of 2 years (inclusive) from the date of purchase. Please keep your receipt as proof of purchase. The warranty does not cover damage caused

The sase need your receipt as proof of put of ase.

The warranty does not cover damage caused due to improper use, non-compliance with safety precautions, accidents, or the incorrect maintenance or commercial use of the device.

This warranty does not cover damage resulting from repairs carried out by persons not authorised by GEONAUTE.

The guarantees contained herein explicitly replace all other guarantees including the implicit

guarantee of merchantability and/or suitability for use. GEONAUTE cannot, under any circumstances, be held responsible for any damage, direct or indirect, of a general or specific nature, caused by or related to use of these instructions or the product they describe.

During the warranty period, the item will either be repaired free of charge by an authorised repair service or replaced free of charge (bepending on the distributor),

The warranty does not cover the battery, or casing that is cracked. broken or presents

4.Declaration of CE conformity

CE

visible dents

OXYLANE hereby declares that the G-EYE REMOTE CONTROL conforms to the major requirements and to other relevant measures in Directive 1999/5/CE. You can read the entire document by following this link:

http://www.geonaute.com/en/ec-declarationconformity

## GeUNaute.com



## OXYLANE

4 Boulevard de Mons – BP 299

59665 Villeneuve d'Ascq cedex - France