





- Your WiFi remote control is **splash proof** (do not submerge) and can control up to 3 cameras at the same time.
- The remote control is compatible with GEONAUTE cameras: G-EYE 300, G-EYE 500 and G-EYE 700.

REMOTE CONTROL DESCRIPTION



CHARGING THE BATTERY


The battery life of the remote control is 4 hours maximum.
Charging the battery takes around 2 hours.





PAIRING PROCEDURE

A. The WiFi on your GEONAUTE camera must be set to STA (see the user manual for your camera: support.geonaute.com) and activated.

B. Switch on your remote control by holding down the button



C. Wait between 20 and 30 seconds



D. Select the number of cameras you want to control:



Scroll down through the menu



Scroll up through the menu



Confirm your choice

E. Control the camera



FUNCTION LIST



- Press and hold: ON/OFF
- Camera in video mode: briefly press to start filming.
- Camera in photo mode: briefly press to switch to video mode.
- Camera in parameters mode: briefly press to confirm your choice.



- Camera in video mode: briefly press to stop filming.
- Camera in parameters mode: briefly press to scroll down.



- Camera in video mode: briefly press to switch to photo mode.
- Camera in photo mode: briefly press to take a photo.
- Hold down (3 seconds): to return to the parameters or change the view modes.
- A short press in parameters mode: to go back and exit the menu.

PRECAUTIONS FOR USE

- After using in a salty environment, gently rinse your remote control with water and allow it to dry.
- Handle the device with care. Do not drop or expose it to serious impacts.
- This product conforms to the waterproofing standard IP67 which means that it can be exposed to rain but cannot be submerged in water.
- For greater safety, do not touch the buttons while in use. Losing concentration can be dangerous.
- Do not disassemble this product as this could cause damage and void the warranty.
- Using this device in extreme cold (at temperatures below -10°C) could cause a decrease in the battery's capacity, and hence reduce the product's battery life.

WARRANTIES, LEGAL NOTICES

LIMITED LIABILITY

- GEONAUTE is not responsible for accidents or injuries that result from handling or use of this product while participating in high-risk sports. Specifically, GEONAUTE wishes to inform the user about the possible risk of losing concentration due to handling the product in dangerous conditions.
- The user is warned that s/he assumes all legal responsibility for the shooting, sharing, and publishing of images captured by this product.

WARRANTY

- GEONAUTE guarantees the original buyer that this product is free of defects due to materials or manufacture for two years starting from the date of purchase. Please ensure that you keep the invoice as proof of purchase.
- The warranty does not cover damage resulting from misuse, from a failure to respect the precautions for use, from accidents, from improper maintenance or from commercial use of the product.
- The warranty does not cover damage resulting from repairs carried out by persons not authorised by GEONAUTE.
- The warranties herein expressly supersede all other warranties, including the implicit warranty of fair marketable quality and/or fitness for purpose. Under no circumstances will GEONAUTE be held liable for any damage, whether direct or indirect, general or specific, caused by or related to the use of this instruction manual or the product it describes.
- During the warranty period, the item will either be repaired free of charge by an authorised repair service or replaced free of charge (depending on the distributor).
- The warranty does not cover the battery or cracked or broken casings showing visible signs of impacts.

LEGAL NOTICES

RECYCLING



The "crossed-out dustbin" symbol indicates that this product and the batteries it contains cannot be disposed of with household waste. They must be disposed of via selective waste sorting.

The product and batteries must be recycled at a collection point at end of life. Recycling your electronic waste protects the environment and your health.

Dispose of your batteries in a place where they will be recycled.

EC DECLARATION OF CONFORMITY



DECATHLON hereby declares that the G-EYE Watch Remote device complies with essential requirements and with other relevant stipulations of the 1999/5/EC directive.

The EC declaration of conformity is available at the following web link:
<http://support.geonaute.com/en-GB/declaration-de-conformite>

CONTACT US

Contact us at www.support.geonaute.com

GEONAUUTE.COM

Fabriqu  en chine
Made in China
Fabricado na China
Произведено в Китае
İmal edildiđi yer Çin
中国 制造
中國 製造
ผลิตในจีน

商标 Geonaute
以下标示仅在中国大陆地区适用
上海莘威运动品有限公司,
上海市闵行区申北路2号
邮编:201108
产品等级 : 合格品
质检证明 : 合格

IMPORTADO PARA BRASIL POR IGUASPORT Ltda
CNPJ : 02.314.041/0001-88

540-0011 大阪市中央区農人橋1-1-22 大江ビル10階
ナチュラムイーコマース株式会社

台灣迪卡儂有限公司
台灣台中市408南屯區大墩南路379號
諮詢電話: (04) 2471-3612

Импортер: ООО «Октобл», 141031, Россия, Московская область,
Мытищинский район, МКАД 84-й км., ТПЗ «Алтуфьево»,
владение 3, строение 3, +7(495)6414446
для занятий спортом

TURKSPORT Spor Ur nleri Sanayi ve Ticaret Ltd.
ŐtiOsmaniye Mahallesi  oban eŐme
KoŐuyoluBulvarı No: 3 Marmara Forum Garden Office
0B Blok 01 Bakırk y 34146 Istanbul, TURKEY

Ref. : 2046553

Производитель и адрес, Франция:

DECATHLON

DECATHLON - 4 Boulevard de Mons - BP 299
59665 Villeneuve d'Ascq cedex - France

