


GEYE

900



DESCRIPTION



short press:
Start/Pause the video

short press:
Take a photo / Take a photo in the video

long press:
Turn on the camera and start recording / stop recording


long press:
Turn on the camera and take a picture



long press:
On/Off



long press:
WIFI On/Off



STEADY GREEN LED

= Camera on




STEADY RED LED


= Video paused or camera charging.

FLASHING RED LED

= Photo or video recording in progress or low battery.




USE WITH WATERPROOF CASE




- Standard rear door (full): waterproof to 20m
To ensure a perfect seal, it is important to keep the seal clean. Rinse with clean water.
- Perforated rear door: for dry and dust-free environments: access the touchscreen and more efficient sound recording.

CHANGING THE REAR DOOR:


Open the case fully, pull on the side of the door until it comes apart. Align the new door with the hinge and close the door until it fits snugly.



MENU



MENU




VIDEO MODES



- FAST SPORTS**
Optimised settings for dynamic sports
1080p (Full HD)
60fps
wide angle and stabiliser
- SLOW SPORTS**
Optimised settings for slow sports
1080p (Full HD)
30fps
wide angle
- TIME LAPSE**
Timelapse video
1photo / 2s, 5s, 10s, 30s, 60s, 300s
- SLOW MOTION**
Slow motion video
720p / 120fps

	RESOLUTION	NTSC (fps)	PAL (fps)	Field of view
	4K	15	12.5	W : Wide
	2.7K	24/30	24/25	W/M : Wide/Medium
	2.7K (4:3)	30	25	W : Wide
	1440P	24/30	24/25	W : Wide
	1080P	24/30/60	24/25/50	W/M/N : Wide/Medium/Narrow
	960P	60	50	W : Wide
	720P	30/60/120	25/50/120	W/M/N : Wide/Medium/Narrow

PHOTO MODES



- Classic photo**
16 MP, 12 MP, 8 MP, 5 MP
- Burst photos**
x30 pics / 1s, 2s, 3s, 6s
x10 pics / 1s, 2s, 3s
x5 pics/s
x3 pics/s
- Timer**
1s, 3s, 5s, 10s, 30s
- Timelapse photo**
1 photo / 2s, 5s, 10s, 30s, 60s, 300s

GENERAL SETTINGS (1/3)

SOUND On Off		LEDS On Off	
ROTATE UP DOWN Auto		LCD STANDBY On Off	
AUTO On/Off On Off		REVIEW On Off	

GENERAL SETTINGS (2/3)

LAST MODE
On
Off

Activate the camera on the last video/photo mode

FAST REC: On Off		PAUSE On Off	
-------------------------------	--	---------------------------	--


Activate the camera and start the video/photo

Activate the pause recording function

GENERAL SETTINGS (3/3)

DISTORTION: On Off		LOOP On Off		OUTPUT PAL NTSC	
RESET ALL factory		FORMAT SD			


VIEW / CONTROL



View, configure and control your camera via the wifi of your smartphone.
Activate the wifi of your camera and of your smartphone then follow the instructions of the application.


REMOTE CONTROL (OPTIONAL)

Pair your remote control by following the procedure after activating the REMOTE function in the camera's general settings.




TV VIEWING

Using a mini-HDMI cable (optional) you can broadcast your photo/video content on an HD television.



ATTACH THE CAMERA



Attach the adhesive mounts to clean, smooth surfaces at room temperature only.
Wait 24 hours before use.

TECHNICAL SPECIFICATION

GEYE900 Weight & Dimensions:
Weight: 106g / 207g w casing
Height: 50mm
Width: 68mm
Depth: 27mm / 36mm with lens

GEYE900 Battery type:
Li-ion Battery, 1480mAh
Main material: ABS

GENERAL PRODUCT SAFETY



Handle the device with care, do not drop or expose it to serious impacts»
Caution, this product is not waterproof without its waterproof case. Do not expose it to water or submerge it

For greater safety, do not touch the buttons while in use. Losing concentration can be dangerous
Do not disassemble this product as this could cause damage and void the warranty
Using this device in extreme cold (at temperature below -10°C) could cause a decrease in the battery's capacity, and hence reduce the product's battery life

LIMITED LIABILITY

DECATHLON is not responsible for accidents or injuries that result from handling or use of this product while participating in high-risk sports. Specifically, DECATHLON wishes to inform the user about the possible risk of losing concentration due to handling the product in dangerous conditions.

The user is warned that s/he assumes all legal responsibility for the shooting, sharing, and publishing of images captured by this product.

EC declaration of conformity

DECATHLON hereby declares that the G-EYE 900 device complies with essential requirements and with other relevant stipulations of the 2014/53/EU directive.

The EC declaration of conformity is available at the following web link:

www.geonaute.com/en/ec-declaration-conformity

RECYCLING



CONTACT US

Contact us at
www.customercare.geonaute.com

Made in China - Fabricado na/em China - Произведено в Китае - İmal edildiği yer Çin - ผลิตในจีน



Производитель и адрес, Франция:
DECATHLON - 4 Boulevard de Mons - BP 299
59650 Villeneuve d'Ascq cedex - France

Импортер/уполномоченное изготовителем лицо: ООО «Октобру», 141031, Россия, Московская область, Мытищинский район, МКАД 84-й км., ТПЗ «Алтуфьево», влд. 3, стр. 3, +7(495)6414446 - Не подлежит обязательному подтверждению соответствия - для занятий спортом - Ровная лапа / Изогнутая лапа / Водонепроницаемый корпус / Шнурок / USB-кабель / Пряжка / Открытая дверь - экшн-камера

主要材料：塑料 - 中國製造 - 進口/委製商台灣迪卡儂有限公司 台中市南屯區大墩南路379號 04-24719666 - 動作相機

Importado Para o Brasil por IGUASPORT Ltda
CNPJ:02.314.041/0001-88

540-0011, 大阪市中央区農人橋1-1-22, 大江ビル10階, ノヴァテックジャパン株式会社

以下标示仅在中国大陆地区适用 - 商标 DECATHLON - 产品名称: GEYE900 - 功能: 用于旅游, 运动时录像和拍照. - 电池: 1480毫安时可充电锂离子电池 - 执行标准: GB/T 29298-2012/GB4943.1-2011 - 生产商: 上海莘威运动用品有限公司 地址: 上海市闵行区申北路2号 邮编: 201204 - 产品等级: 合格品 - 质检证明: 合格 - 运动相机

TURKSPORT Spor Ürünleri Sanayi ve Ticaret Ltd.Şti Osmaniye Mahallesi Cöbancıme Koşuyolu Bulvarı No: 3 Marmara Forum Garden Office 0B Blok 01 Bakırköy 34146 İstanbul, TURKEY



WWW.DECATHLON.COM