
VE 630

NOTICE D'UTILISATION
OPERATING INSTRUCTIONS
MODO DE EMPLEO
GEBRAUCHSANWEISUNG


ISTRUZIONI PER L'USO
GEBRUIKSHANDLEIDING
MANUAL DE UTILIZAÇÃO
INSTRUKCJA UŻYTKOWANIA


使用说明书





DOMYOS


MONTAGE • ASSEMBLY • MONTAJE • ZUSAMMENBAU • MONTAGGIO • AFWERKING • MONTAGEM • MONTAZ • 安装























(17) X10



18) X6 M8X20



(19) X4 M8X70



②0X8 M4X15



29X4 M8X25




(48)X8



You have chosen a DOMYOS fitness machine and we wish to thank you for the trust you place with us.

We created the DOMYOS brand to enable all sports aficionadoes to remain at peak fitness. This item was designed by sportsmen for sportsmen and women. We would very much appreciate receiving any of your comments and suggestions about DOMYOS products. To this aim, the staff at your local store and the DOMYOS design department are at your disposal. If you wish to write to us, you can send us email at the following address: domyos@decathlon.com

If you wish to write to us, you can send us email at the following address: domyos@decathlon.com
We wish you enjoyable training sessions and hope that this DOMYOS item be a source of pleasure for you.



Model N°: Serial N°: Write the serial number in the space above for future reference. Serial number Decal

CAUTION

Read all warnings affixed to the product.

Read precautions and instructions in this manual before using this equipment.

Keep this manual for future reference.

PRESENTATION

The VE630 is a new generation exercise bike.

This product is equipped with magnetic transmission for greater pedaling comfort without jolts. The VE630 associates a bike's circular movements, a runner's horizontal movements and a stepper's vertical movements: it is complete!

The front and back elliptical movements of the feet together with the movement of the arms develops the muscles in the arms, dorsal, pectorals, buttocks, quadriceps and the calves.

SAFETY


Warning: to reduce the risk of serious injury, please read the important precautions below before using the product.


- Read all the instructions in this manual before using the product. Use this product only in the way described in this manual. Keep this manual during the product's service life.
- This appliance is in compliance with European, American and Chinese standards related to fitness products for domestic and non-therapeutic use (EN-957-1, EN 957-9 classe HC / GB17498).
- An adult should do the assembly of the appliance.
- 4. It is up to the owner to make sure that all of the product's users are properly informed on all the user precautions.
- 5. DOMYOS disclaims all responsibility concerning claims for injury or for damages suffered by any persons or property arising from the normal or abnormal use of this product by the purchaser or by any other person (valid only in the United States).
- The product is intended for domestic use only. Do not use the product in a commercial, rental or institutional context.
- 7. Use the product indoors, away from moisture and dust, on a level and solid surface and in a clear area. Be sure there is enough space for safe access to the elliptical bike and passage around the product. Cover the floor beneath the product for protection.
- 8. It is the user's responsibility to ensure efficient maintenance of the appliance. After assembling the product and before each use, check that the attachment elements are well tightened without extending. Check the state of wear and tear parts.
- In the event of damage to your product, have all worn out or defective parts replaced immediately by the After-Sales Service of your nearest DECATHLON store and do not use the product before it is completely repaired.
- 10. Do not store the product in a humid place (edge of swimming pool,
- 11. Always wear sports shoes to protect the feet while exercising. Wear appropriate clothing when exercising. DO NOT wear loose clothing that could get caught in moving parts. Remove jewellery.
- 12. Tie long hair so that it does not get in the way when exercising.
- 13. If you feel pain or dizziness while exercising, stop immediately, rest

- a while and consult your doctor.
- 14. Keep children and pets away from the product at all times.
- 15. Keep hands and feet away from moving parts.
- 16. Before starting an exercise program, you should consult a doctor to make sure that there are no counter-indications especially if you have not practiced any sport for several years.
- 17. Do not let setting devices extend outward.
- 18. Do not tinker with your VE630.
- Keep your back straight when using the product. Do not arch your back.
- 20. The heart rate sensor and the body fat measurer are not medical devices. Various factors may affect the accuracy of rate readings. The heart rate sensor is intended only as exercise help in determining heart rate trends in general. The body fat measurer is intended only as exercise help in determining body fat rate trends in general.
- 21. Notice to persons with pacemakers, defibrillator or other implanted electronic device. Persons who have a pacemaker use the pulse sensor and the body fat measurer at their own risk. Before starting the exercise programme, an exercise test under the supervision of a doctor is recommended.
- 22. Pregnant women are not advised to use the VE630 pulse sensor and body fat measurer. Please consult your doctor before using it.
- 23. Always hold the handlebar when getting on, getting down, or using the product.
- 24. Care should be taken mounting/dismounting the exercise bicycle.
- 25. When you stop exercising, allow the pedals to slowly come to a stop.
- 26. Maximum user weight: 110 kg 242 pounds.

WARNING

Consult your doctor before starting an exercise program. This is particularly important for people over 35 or having had health problems before. Read all the instructions before use.






A WARNING

- . Misuse of this product may result in serious injury.
- Read user's manual and follow all warnings and operating instructions prior to use.
- . Do not allow children on or around
- Replace label if damaged, illegible,
- · Keep hands, feet and hairs away from moving parts.

SETTINGS

Warning: It is necessary to get off the elliptical bike to proceed to the settings.



1 TO ADJUST THE POSITION 3 SETTING THE RESISTANCE OF THE PEDALS

For comfortable pedaling at the level of the calves, the height of the arms / pedals support tube link can be adjusted.

To adjust the height of the pedals support tube (05), hold the tube and loosen button (13) on the arm. Align one of the holes on the pedals support tube (05) with that of arm (03/04). Retighten button (13) back in place.

Repeat the procedure on the other

Always exercise with the same setting on both sides.

CAUTION:

- · Make sure the button is placed back in the pedals support tube and fully tighten it.
- Never overshoot the maximum

HOW TO LEVEL THE BIKE

If the bike rocks during use, turn one or both plastic caps (32) at the end of the back foot (7) until the rocking stops.

he brakes system and the resistance are coupled with the pedaling speed.


The resistance setting is done with the knob indexed (43) from 1 to


Position 1 corresponds to the least resistance and position 8 to the highest resistance.

You can adjust the resistance while pedaling.

VE630 METER

FULL LCD DISPLAY





KEY GUIDE

- 1. Select function to be preset. Gender-Height-Weight-Age-Time-Distance-Calorie-Pulse
- 2. Press this button to enter setting mode.
- 3. Press this button to confirm the setting values.
- 4. Hold two seconds to reset all of the values to zero.
- 5. Hold over 5 seconds, the display and function will return to preset your personal data for body fat measuring.

HEART RATE:

Press this button to detect your heart rate.

Press this button to access your body fat measurement. Before operating this function, you have to enter your personal data in monitor.

- Increase the setting value of the following functions. Gender -Height-Weight-Age-Time- Distance-Calorie-Pulse
- 2. Select function and display on the main screen during exercise. Scan-Time-Speed- Distance - Calorie - Pulse.

- 1. Decrease the setting value of the following functions. Gender Height-Weight-Age-Time- Distance-Calorie-Pulse
- 2. Select function and display on the main screen during exercise. Scan - Heart rate-Calorie-Distance-Speed-Time.

FUNCTIONS AND OPERATIONS

The monitor will turn on automatically if the exercise machine is in motion. If you stop exercising for over 4 minutes, the monitor will turn off and reset all function values to zero.

Press the UP or DOWN button until the scanning dot flashes on the screen. The Monitor will display the following functions and each function will remain on the main screen for 5 seconds. Time-Speed-Distance-Calories-Heart rate.

Press the UP or DOWN button until the TIME dot displays on the screen. Monitor will display the Time function on the main screen. If you want to setup the value, please press the ENTER/RESET to TIME function button and press the UP or DOWN button to enter the value

- . Count up: Without setting the time value, the monitor will count up the time from 00:00~99:59.
- . Count down: Setting the exercise time from 1:00~99:00 minutes, the monitor will count down from your setting values. Once the setting value is reached, the monitor will set off an alarm.

Press the UP or DOWN button until the SPEED dot displays on the screen. The monitor will display the current speed on the main screen. The monitor will display the current speed from 0.00 ~ 99.9 Km/h or Mile/h (USA only).

ENGLISH

ENGLISH

DISTANCE

Press the UP or DOWN button until the DIST dot displays on the screen. The Monitor will add the distance covered. If you want to setup the value, please press the ENTER/RESET to DIST button and press the UP or DOWN button to enter the value you want.

 Count up: Without setting the distance value, the monitor will count up the distance from 0.1~999.9Km or Mile (USA only).

 Count down: Setting the exercise distance from 1.0~999.0 Km or Mile (USA only), the monitor will count down from your setting values. Once the setting value is reached, the monitor will set off an alarm.

CALORIES :

Press the UP or DOWN button until the CAL dot displays on the screen. The Monitor will add the calorie consumption. If you want to setup the value, please press the ENTER/RESET to CAL button and press the UP or DOWN button to enter the value you want.

 Count up: Without setting the distance value, the monitor will count up the distance from 0.1–999.0.

 Count down: Setting the exercise calorie from 1.0~999.0, the monitor will count down from your setting values. Once the setting value is reached, the monitor will set off an alarm.

Warning: this is an estimate and should in no case be taken as a medical indication.

PULSE (Target Heart Rate):

Press the UP or DOWN button until the pulse dot displays on the screen. The monitor will display your current heart rate in beats per minute. If you want to setup the value, please press the ENTER/RESET to T.H.R. button and press the UP or DOWN button to enter the value you want.

Pulse Limit:

Setting the value of pulse limit between 60 to 220, the monitor will measure your heartbeats. Once the setting value is reached, the monitor will flash until your heart beats below your setting value. Place the palms of your hands on both of the contact pads and the monitor will show up your heartbeat rate in beat per minute (BPM) on the LCD display.

NOTE

If no pulse signal input within 16 seconds, the display will indicate "P". It is a power saving device. Customer can press the up & down keys to restart Pulse function

Warning: this is an estimate and should in no case be taken as a medical indication.

HEART RATE RECOVERY:

This is a function to check the condition of pulse recovery when exercising has stopped. This is scaled from F1.0 to F6.0 where F1.0 is the best, F6.0 is the worst, and the increment is 0.1. This function may reflect your heart pulse recovery ability and improve it through exercise. In order to get a correct rating, users must test it straight after the finish of the workout by pressing the "RECOVERY" key and then stop exercising. After the key is pressed, please also apply the heart rate detector appropriately. The test will last for 1 minute and the result will show in the display. When pressed again it will exit the HEART RATE RECOVERY mode.

BODY FAT MEASUREMENT (Body Mass Index):

When you turn on the monitor or press the ENTER/RESET button for over 6 seconds, the monitor will go into BODY FAT MEASUREMENT function. Before pressing the MEASURE button to measure your body fat, you have to enter your personal data into the monitor. Select the personal data and press the UP or Down button to enter your personal data. Then press MEASURE button and place the palms of your hands on both of the contact pads. The monitor will show your body fat ratio on LCD. The default value of personal data is described as follows. The personal data will not be retained in the monitor when the monitor power is off or being reset.

GENDER: male, HEIGHT: 175 cm, WEIGHT: 70 kg, AGE: 30 years

A. Body Types: There are 9 body types divided according to the FAT% calculated. Type 1 is Ultra-sportsman type. Type 2 is Ideal-sportsman type. Type 3 is Ultra Slim type. Type 4 is Sportsman type. Type 5 is Ideal-healthy Type. Type 6 is slim type. Type 7 is too fat. Type 8 is Fat type. Type 9 is Ultra body fat type.

B. BMR: Basal Metabolism Ratio. The monitor will calculate the data of gender, height, weight and age to show your value. The value will show on the screen from 1 ~ 9999 Kcal.

C. BMI: Body Mass Index. The monitor will calculate the data of height and weight to show your value. The value will show on the screen from 1.0 ~ 99.9 on screen.

D. FAT %(BODY FAT RATIO): The monitor will calculate the data of gender, height, weight and age to show your BODY FAT RATIO. The value will show on screen from 5 ~ 50%.

Warning: this is an estimate and should in no case be taken as a medical indication.

BATTERY REPLACEMENT

- Insert 2 batteries type AA or UM-3 into the battery compartment in the back of the monitor.
- Ensure that the batteries are correctly fitted and correctly positioned, make sure the battery spring is in proper contact with the battery.
- If the display appears blank or displays only partial segment, remove the batteries and wait 15 seconds, then reinstall the battery.
- Whenever the batteries are removed, all the functions values will reset to zero.
- The batteries must be removed from the appliance before it is scrapped and must be disposed of safely.
- 6. Take old batteries to recycling centers intended for that purpose.

PARTS OF THE BODY DEVELOPED

The elliptical bike is an excellent form of heart-training activity. Training on this appliance aims at increasing your cardio-vascular capacities. By this principle, you improve your physical fitness, your endurance and you burn calories (an essential activity for losing weight in association with a diet). Finally, the elliptical appliance allows you to tone up the legs, the buttocks and the upper body (bust, back and arms). The calve muscles and the lower part of the abdominals are also exercised.

You can consolidate the work of the buttocks by pedaling in a backward movement.

USAGE

If you are a beginner, start training for several days with a feeble resistance, without forcing, and if necessary taking the time to rest. Progressively increase the number or the length of training sessions.

Keeping fit / warming up: Progressive effort starting with 10 minutes.

To maintain one's fitness or for re-education, you can do training every day for ten minutes. This type of exercise will keep muscles and articulations fit or it can be done for warming up in view of physical activity. To increase the toning up of legs, select a more important resistance and increase the training time.

Of course, you can vary the resistance throughout your training session.

Aerobic training for physical fitness: Moderate effort during a long time length (35mn to 1 hour).

If you want to lose weight, this type of exercise, together with a diet, is the only means of increasing the quantity of energy consumed by the organism. To do so, there is no use forcing beyond one's limits. Only the regularity of training allows obtaining the best results.

Select a relatively feeble resistance and do the exercise at your rhythm but for at least 30 minutes. This exercise should make a bit of sweat appear on the skin but should in no case make you get out of breath. It is the length of the exercise, on a slow rhythm that will make your organism draw its energy in your reserves of fat on the condition of rowing for over thirty minutes, at least three times a week.

Aerobic training for endurance: Sustained effort for 20 to 40 minutes.

This type of training aims at a significant reinforcement of the cardiac muscle and the improvement of breathing.

The resistance is increased so as to increase breathing pendant the exercise. The effort is more sustained than for fitness exercising. As the training progresses, you will be able to stand the effort longer, on a better rhythm or with greater resistance. You can do training at least three times a week for this type of training.

Training on a more forceful rhythm (anaerobic and red zone exercising) is reserved for athletes and requires an adapted preparation.

After each training session, devote a few minutes to rowing while lessening the speed and the resistance in order to calm down and progressively

bring the organism to rest.

TRADE WARRANTY

DECATHLON guarantees this product for parts and labor, under normal conditions of use, for 5 years for the structure and 2 years for wear parts and labor starting on the date of purchase, confirmed by the date on the sales ticket..

DECATHLON'S obligation in compliance with this warranty is limited to the product's replacement or repair, at DECATHLON'S convenience. To have the product repaired, bring it to a DECATHLON store.

This warranty cannot be applied in the following cases:

- Damage caused during transport
- Misuse or abnormal use
- Repairs done by people not authorized by DECATHLON
- The commercial use of the product concerned

This trade warranty does not exclude the legal guarantee(s) applicable according to countries and / or provinces.

DECATHLON

- 4 BOULEVARD DE MONS BP299 -
- 59665 VILLENEUVE D'ASCQ France -

Н G

CARDIO-TRAINING EXERCICE

Cardio-training exercice is a form of aerobics (conditioning the body in the presence of oxygen) and allows you to improve your cardio-vascular capacity. To be more precise, you will improve the tonicity of the heart and your blood vessels. Cardio-training exercice carries the oxygen breathed in from the air to your muscles. It is the heart that pumps this oxygen through the body and, in particular, to the muscles being exercised.

CONTROLLING YOUR HEARTBEAT

It is vital to measure your pulse periodically in order to control your degree of exercising. If you do not have an electronic measuring device, follow this procedure:

To take your pulse, position two fingers : on the neck, or below the ear, or at the inside wrist beside the thumb.

Do not press too hard: excessive pressure reduces the blood flow

and can slow down the heartbeat. After counting the pulsations for 30 seconds, multiply by 2 to obtain the number of pulsations per

Example: 75 pulsations counted in 30 seconds corresponds to a heart beat of 150 pulsations per minute.

PHASES OF A PHYSICAL ACTIVITY

Warm-up phase : progressive effort.

Warming up is a preparatory phase before any activity. It puts the person INTO OPTIMUM CONDITIONS for carrying out his or her favorite sport. It is a METHOD OF PREVENTING ACCIDENTS TO TENDONS AND MUSCLES. There are two aspects: WAKING UP THE MUSCULAR SYSTEM, GENERAL WARMING UP.

- 1) The muscular system is prepared in a SPECIAL STRETCHING SESSION which PREPARES FOR EACH ACTIVITY: each group of muscles is used, joints are used.
- 2) Global warming up gradually brings the cardiovascular and respiratory system into action, improves irrigation of the muscles and prepares for making efforts. It must be sufficiently long: 10 min for a leisure sport activity, 20 min for a competition sport activity. Note that warming up must be longer: after 55 years old, in the morning.

(1) Training

TRAINING is the main phase of your physical activity. You can improve your physical condition by REGULAR training.

- · Anaerobie exercice to develop endurance,
- Aerobic exercice to develop cardio-pulmonary resistance.


Slowing down

This is the continuation of an activity at low intensity, the gradual "return to rest" phase. SLOWING DOWN brings the cardiovascular and respiratory system, the blood flow and muscles back to "normal" (eliminating the counter effects of an exercice, such as lactic acids, the accumulation of which is one of the major causes of muscular pains such as cramps and stiff muscles).

Stretching

STRETCHING must follow the slowing down phase while joints are still warm in order to reduce risks of injury. Stretching after an activity: minimizes MUSCULAR STIFFNESS due to an accumulation of LACTIC ACIDS, "stimulates" BLOOD CIRCULATION

Exercice range



- Exercise from 80 to 90% and beyond: Anaerobic zone and red zone reserved for high performance and specialised athletes.
 - Exercise of 70% to 80% of the maximum cardiac rate : Endurance exercise.
- Exercise from 60 to 70% of the maximum cardiac rate: Getting fit / favourable consumption of
 - Exercise from 50 to 60% of the Maintenance /Warm up

WARNING, TECHNICAL INSET -WARNING TO USERS

You must work towards getting fit in a controlled

Do no hesitate to consult a doctor before any physical activity, especially if; you have not practiced any sports activities in recent years, you are more than 35 years old, you are not sure about your health, you are following medical

CONSULT A DOCTOR BEFORE PRACTISING ANY SPORT.